

- 1. OVERVIEW ..... 1
  - 1.1. SPECIFICATIONS ..... 2
    - 1.1.1. Electrical ..... 2
    - 1.1.2. Physical ..... 2
  - 1.2. COOLING ..... 2
    - 1.2.1. Fan Exhaust ..... 3
  - 1.3. MOUNTING ..... 3
  - 1.4. POWER ..... 3
    - 1.4.1. Turning the Power On and Off ..... 3
    - 1.4.2. Power Supply Status Indicators ..... 4
- 2. FRAME STATUS FAULT CONDITIONS ..... 5
  - 2.1. FRAME STATUS TALLY TERMINAL BLOCK ..... 5
- 3. INSTALLING AND REMOVING THE MODULES ..... 5
  - 3.1. OPENING AND CLOSING THE FRONT PANEL ..... 5
  - 3.2. INSTALLING THE MODULES ..... 6
  - 3.3. REMOVING THE MODULES ..... 6
- 4. SERVICING INSTRUCTIONS ..... 6
  - 4.1. CHANGING THE FUSES ..... 6
  - 4.2. REPLACING THE POWER SUPPLY ..... 6

**Figures**

- Figure 1: 500PS Status Indicators ..... 4
- Figure 2: Locating the Power Supply Mounting Screw ..... 7

**Tables**

- Table 1: Frame Status Tally Terminal Block Pin Assignments ..... 5

## REVISION HISTORY

<u>REVISION</u>	<u>DESCRIPTION</u>	<u>DATE</u>
1.0	Original Version	Aug 02
1.1	Updated Power specification	Aug 04
1.2	Updated Safety instructions and specification	May 05
1.2.1	Added max power consumption, max current and max load specifications	Jul 05
1.3	Added 500FR-L-A (Analog) and 500FR-L-D (Digital) Loop Thru frames Added GROC relay specs	Jan 06
1.4	Updated Power Supply LED descriptions, added Frame Status section	Jul 06

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof or for the rights of third parties, which may be effected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance, either express or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.

## 1. OVERVIEW

The 500FR is a 3 rack unit high rack frame for the 500 series **exponent** modular system. This advanced rack frame design can house up to 16 of the 500 series distribution, conversion and processing modules in any combination. Special care was taken during the design process to ensure that the 500FR meets the demanding needs of television studios today has sufficient flexibility to satisfy the emerging demands of the future.

The 500FR is designed with a high density capacity to conserve on precious equipment rack space. Care has been taken to ensure sufficient thermal relief for up to 120 watts of processing power per frame, to meet the increasing power demands of future high speed processing cards.

Hot swappable redundant switching power supplies and cooling fans allow power supply or fan replacement without compromising the integrity of critical signal paths.

The front loading design permits extraction of the power supplies and active modules from the front without compromising performance even at 1.5Gb/s. Thus, there is no need for time consuming re-cabling nor is there need to have access to the rear of the frame replace or exchange modules.

The Frame is available in different versions to suit a variety of applications. Throughout this manual, references to 500FR refer to all models of the frame unless otherwise specified.

Model	Description
500FR	AC powered frame. This frame supports all 500 series modules <b>EXCEPT</b> analog or digital loop through modules.
500FR-L-A	AC powered frame with loop thru capability for analog video signal. This frame supports <b>ONLY</b> analog loop thru modules.
500FR-L-D	AC powered frame with loop thru capability for digital video signal. This frame supports <b>ONLY</b> digital loop thru modules.

### Features:

- Houses up to 16 processing modules. Use 500FR-L versions for loop through modules.
- Front monitoring window for verifying module and power supply status
- Frame status contact closure alarm signals power supply or fan failures and user selectable module alarms
- Front extractable modules, power supplies and fans
- Auto-ranging power supply operates from 90-250vac at 60/50hz
- Power supply and frame cooling fans are fully redundant and hot-swappable
- High-speed bussing and control system provided for modular applications

### Additional Features (500FR-L-A and 500FR-L-D versions only)

- Ability to provide a single input source to multiple loop thru modules in a single frame
- Hot swapping of loop thru modules without impacting input signal to other loop thru modules
- Supports up to 16 Analog loop thru modules (500FR-L-A only)
- Supports up to 16 (SD) or 12 (HD) Digital loop thru modules (500FR-L-D only)

## 1.1. SPECIFICATIONS

### 1.1.1. Electrical

<b>AC Mains Input</b>	Auto ranging, 100 ⇔ 240 VAC, 50/60 Hz
<b>Maximum Operating Current:</b>	2.6 A (@ 120 VAC), 1.4 A (@ 240 VAC)
<b>Maximum Power Consumption:</b>	200 W
<b>Maximum Module Load:</b>	160 W (10 W per slot)
<b>Power Supply Configuration</b>	Dual, redundant, separate AC inlets
<b>Connector:</b>	IEC 60320 - 1 per power supply
<b>Fuses:</b>	4 amp, 250 volt time delay 5 x 20 mm. – 2 per power supply
<b>Safety:</b>	CSA Listed to CSA C22.2 No. 60065-03, UL 60065-03 IEC 60065-(2001-12) 7th Edition Complies with CE Low voltage Directive 93/68/EEC
<b>EMC:</b>	Complies with FCC part 15, class A. Complies with EU EMC directive 89/336/EEC
<b>Status Indicators:</b>	PSU status LED Local Error/Failure LED
<b>Tally Output Connector:</b>	4 pin terminal, relay N/O, N/C for status/fault alarm, 2 A, 125 VDC max
<b>Temperature:</b>	0 - 40°C

### 1.1.2. Physical

<b>Height:</b>	5.25" (133 mm)
<b>Width:</b>	19" (483 mm)
<b>Depth:</b>	9.5" (368 mm)
<b>Module Capacity:</b>	16 slots
<b>Weight:</b>	Approx 17 lbs (7.7 Kg) with 2 power supplies, no slots occupied Approx. 32 lbs. (14.5 Kg) with 2 power supplies all slots occupied

## 1.2. COOLING

The 500FR frame is designed to ensure adequate cooling for up to 120 watts of processing power per frame. Fans at the front and rear of each power supply module accomplish forced air cooling. Adjacent equipment may be mounted immediately to the top and bottom of the 500FR frame. Additional module cooling is provided by interior cooling channels to ensure that even fully loaded frames mounted adjacent to each other will operate within the normal temperature range.



**For proper cooling, the frame must contain either two 500PS power supplies, or one 500PS power supply and one 500PS-FM power supply blank panel with cooling fan.**

### 1.2.1. Fan Exhaust

The cooling fans for the power supplies, located at the front of the frame, draw air in the front and exhaust out the sides of the frame. The cooling fans for the modules, located at the rear of the frame, draw air in the front and the exhaust out the rear of the frame.



**CAUTION: To ensure adequate cooling, care should be taken to ensure that the fan inlets and exhaust openings are free of obstructions.**

### 1.3. MOUNTING

The 500FR Rack frame requires 3 rack units i.e. 5.25 inches (133 mm) of standard.19 inch (483 mm) wide rack space. To securely fasten the frame to the equipment rack, make sure that all four mounting screws are tightened securely.

### 1.4. POWER

The 500FR frame comes standard with one auto-ranging power supply that automatically senses the input voltage. An additional power supply (500PS) can be ordered to provide fully redundant powering of the frame. When only one power supply is fitted, the frame will be fitted with a 500PS-FM fan module to ensure the thermal integrity of the frame cooling. Power should be applied by connecting a 3-wire grounding type power supply cord to the power entry module on the rear panel of each power supply. The power cord should be minimum 18 AWG wire size; type SVT marked VW-1, maximum 2.5 m in length.

The power entry modules contain a standard IEC power inlet connector, two 5 x 20 mm fuse holders and an EMI line filter.




**CAUTION - TO REDUCE THE RISK OF ELECTRIC SHOCK, GROUNDING OF THE GROUND PIN OF THE MAINS PLUG MUST BE MAINTAINED**

#### 1.4.1. Turning the Power On and Off

Each 500PS power supply is fitted with its own power switch. When the switch is turned off, the remaining power supply will power the 500FR frame. To completely remove power from the frame, both power supplies must be turned off.

### 1.4.2. Power Supply Status Indicators



**Figure 1: 500PS Status Indicators**

Each power supply has two status indicator LEDs. The green PSU STATUS LED indicates the health of the local power supply. The red FRAME STATUS LED indicates the health of the entire frame and is operated by the frame status buss of the frame. The FRAME STATUS LED will be Off under normal conditions and On when there are Frame Status Fault conditions. See section 2 for more information about frame status buss fault conditions.

If one of the power supplies malfunctions, (power cord disconnected, power switch is off, fuse is blown, rear fan is stopped, etc,) then its PSU STATUS LED will go Off, and the red FRAME STATUS LED on both power supplies will turn On. (If the power supplies are fitted with green FRAME STATUS LEDs they will turn Off) The PSU STATUS LED on the power supply that is functioning will remain On. If the frame is connected to VistaLINK<sup>®</sup> then the power supply fault will send a trap message from the frame.



**If there is a fuse failure, contact Evertz customer service regarding the power supply immediately. The power supplies are short circuit protected and should not blow the fuse under a short circuit condition.**

## 2. FRAME STATUS FAULT CONDITIONS

The Frame is fitted with a global Frame Status monitoring buss that is connected to each of the power supplies and to each of the modules. When a fault condition occurs on one of the power supplies, or one of the modules, a Frame Status Fault condition is active on the frame status buss. When this occurs the red FRAME STATUS LED on the power supply will come on and the relay on the Frame Status Tally terminal block will activate.

Power supplies, will assert a frame status fault when their PSU STATUS LED is off.

Each module has a large red LOCAL FAULT LED and a large green MODULE OK LED at the top of the card edge. This green LED indicates good module health while the red LED indicates that there is a fault condition on the module. Each module has its own criteria that determines when the red fault LED comes on. When the red LOCAL FAULT LED is On the module can also assert a fault condition on the Frame Status buss. On each module there is a jumper that disables sending local card fault information to the Frame Status Buss. For more information about fault conditions on individual modules, and for the location of the Frame Status Jumper on the module consult the individual chapter for the module. For example, if a module requires video or audio for its functionality and the video or audio is not present, the red LOCAL FAULT LED on the module will be On and the fault will be reported on the frame status buss if the FRAME STATUS jumper on the module is set to the On position (default).

### 2.1. FRAME STATUS TALLY TERMINAL BLOCK

There is a green **FRAME STATUS** terminal block at the rear of the frame that has a normally open and normally closed relay contact that can be used to indicate frame status fault conditions to external equipment. There are 4 connections.

Label	Pin #	Function
G	1	Chassis Ground (connect to cable shield)
R	2	Common (connect to Ground or your reference)
O	3	Open with respect to common when Frame Status fault exists
C	4	Closed with respect to common when Frame Status fault exists

**Table 1: Frame Status Tally Terminal Block Pin Assignments**

The relay contacts can sink up to 2A and operate up to 125 VDC.

## 3. INSTALLING AND REMOVING THE MODULES

### 3.1. OPENING AND CLOSING THE FRONT PANEL

In order to insert or remove modules you will have to open the front panel. Turn the two captive screws located on the front panel counter clockwise several turns until they release completely from the front extrusions. Carefully lower the front panel door so that the front edge of the door is lower than the rear of the door.

### 3.2. INSTALLING THE MODULES

Orient the module vertically such that the white card ejector is on the bottom. Align the card with the card guide corresponding to the slot number where you installed the rear panel plate. Carefully slide the module into the frame and press it completely into the rear panel connectors. Make sure that the connectors are fully seated in the rear panel.

### 3.3. REMOVING THE MODULES

Press the card ejector down to release the module. Grasp then the card using the card ejector and pull the module out from the frame. As the card ejector goes past the front extrusion, you will have to pull it with slightly more force. Carefully place the module in a safe place, free from static discharge.

## 4. SERVICING INSTRUCTIONS



**CAUTION – These servicing instructions are for use by qualified service personnel only. To reduce risk of electric shock do not perform any servicing instructions in this section of the manual unless you are qualified to do so.**

### 4.1. CHANGING THE FUSES

The fuse holder is located inside the power entry module. To change the fuses, pull out the fuse holder from the power entry module using a small screwdriver. The fuse holder contains two fuses, one for the line and one for the neutral side of the mains connection. Pull out the blown fuse and place a fuse of the correct value in its place. Use time delay 5 x 20 mm fuses rated for 250 Volts with a current rating of 4 amp. (T4AL250V) For your convenience there are spare fuses located in the vinyl pouch in the front of this manual. Carefully reinsert the fuse holder into the power entry module.



**Check that the line fuse is rated for the correct value marked on the rear panel. Never replace with a fuse of greater value.**

### 4.2. REPLACING THE POWER SUPPLY

Each power supply is a complete assembly and includes the power supply cooling fan and one frame cooling fan. In the event that the power supply or one of the fans malfunctions, you will need to replace the power supply assembly with a spare one while the failed assembly is being repaired.



**Do not run the frame for extended periods of time with one of the power supplies removed. Proper cooling of the frame requires both power supplies to be inserted into the frame, or one power supply and a 500PS-FM power supply blank panel.**




The 500FR power supplies are hot swappable and can be easily replaced from the front without interrupting the signal integrity of the frame. Each power supply is capable of supplying full power to the frame by itself. However, we recommend running both power supplies for power redundancy and cooling.

On frames with only one power supply, a 500PS-FM blank power supply module with cooling fan **must be** inserted into the second power supply space. The 500PS-FM contains a module cooling fan and baffles to maintain proper airflow within the frame.

The power supply is secured into the frame by a machine screw through the rear panel (as shown in Figure 2). This screw must be removed before the power supply can be extracted from the front.



**To reduce risk of electric shock you must replace the mounting screw after replacing the power supply.**



**Figure 2: Locating the Power Supply Mounting Screw**

---

To replace the power supply the following procedure should be used.

1. Turn off the power supply switch
2. From the rear of the frame locate the power supply mounting screw. This screw is the top right screw holding the fan guard in place, and is indicated by the legend

PSU  
MNT ↓

3. Remove the power supply mounting screw.
4. Open the front door of the frame and pull the power supply out of the frame.
5. Reinsert the new power supply into the frame taking care that it is properly aligned with the card guides. Press firmly to make sure that the power supply is fully seated into the rear panel connector.
6. Reinstall the power supply mounting screw from the rear of the frame.
7. Turn on the power switch for the power supply. After a few seconds you should see the PSU STATUS LED come on indicating that the power supply is working correctly.