

---

---

## TABLE OF CONTENTS

|        |  |    |
|--------|--|----|
| 1.     | OVERVIEW .....   | 1  |
| 2.     | INSTALLATION.....                                      | 3  |
| 2.1.   | INSTALLING THE GPIO PANEL ADAPTER .....                | 4  |
| 2.2.   | CONNECTING THE GENERAL PURPOSE INPUTS AND OUTPUTS..... | 5  |
| 2.2.1. | GPO Behaviour .....                                    | 6  |
| 3.     | SPECIFICATIONS.....                                    | 7  |
| 3.1.   | RELAY INPUTS .....                                     | 7  |
| 3.2.   | RELAY OUTPUTS .....                                    | 7  |
| 3.3.   | GENERAL PURPOSE INPUTS AND OUTPUTS .....               | 7  |
| 3.4.   | ELECTRICAL.....  | 7  |
| 3.5.   | PHYSICAL .....   | 7  |
| 3.6.   | SIGNAL PRESENT AND CHANGEOVER CONDITIONS.....          | 7  |
| 4.     | STATUS LEADS .....                                     | 8  |
| 4.1.   | MODULE STATUS LEADS .....                              | 8  |
| 4.2.   | SIGNAL PRESENT LEADS.....                              | 8  |
| 4.3.   | INPUT SELECTED LEADS .....                             | 8  |
| 5.     | MODES OF OPERATION.....                                | 9  |
| 5.1.   | ACO EXTENSION MODE .....                               | 10 |
| 5.2.   | GPI CONTROL MODE.....                                  | 11 |
| 5.3.   | AUTO CHANGEOVER MODE .....                             | 11 |
| 5.3.1. | DVB-ASI Exclusive Mode.....                            | 12 |
| 5.3.2. | Setting the Switching Priority Mode .....              | 12 |
| 5.3.3. | ACO1 Master Mode .....                                 | 13 |
| 5.3.4. | ACO1 Master Mode with GPI Override .....               | 13 |
| 5.4.   | MANUAL DIP SWITCH CONTROL MODE.....                    | 14 |

|           |   |           |
|-----------|---|-----------|
| <b>6.</b> | <b>JUMPERS AND USER ADJUSTMENTS.....</b>  | <b>15</b> |
| 6.1.      | SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED<br>BY THE GLOBAL FRAME STATUS..... | 16        |
| 6.2.      | CONFIGURING THE MODULE FOR FIRMWARE UPGRADES.....                                   | 16        |
| <b>7.</b> | <b>VISTALINK® REMOTE MONITORING/CONTROL.....</b>                                    | <b>17</b> |
| 7.1.      | WHAT IS <i>VistaLINK</i> ®? .....   | 17        |
| 7.2.      | <i>VistaLINK</i> ® MONITORED PARAMETERS .....                                       | 18        |
| 7.3.      | <i>VistaLINK</i> ® CONTROLLED PARAMETERS .....                                      | 18        |
| 7.4.      | <i>VistaLINK</i> ® TRAPS.....   | 18        |

**Figures**

|             |  |    |
|-------------|--|----|
| Figure 1-1: | 500ACO2-HD/SD Block Diagram .....                        | 2  |
| Figure 2-1: | 500ACO2-HD/SD Rear Panel Overlay and Panel Adapter ..... | 3  |
| Figure 2-2: | K500AMDA-IO Rear Panel Adapter Installation.....         | 4  |
| Figure 2-3: | GPI Circuitry .....                                      | 5  |
| Figure 2-4: | GPO Circuitry .....                                      | 5  |
| Figure 5-1: | ACO Extension Mode Diagram .....                         | 11 |
| Figure 6-1: | LED and Jumper Locations.....                            | 15 |

**Tables**

|             |  |    |
|-------------|--|----|
| Table 5-1:  | Mode Selection DIP Settings.....                           | 9  |
| Table 5-2:  | GPO Operation in ACO Extension Mode .....                  | 10 |
| Table 5-3:  | GPI Control Mode for GPI in/out 1 .....                    | 11 |
| Table 5-4:  | GPI Control Mode for GPI in/out 2 .....                    | 11 |
| Table 5-5:  | Auto changeover Behavior for each 2X1.....                 | 11 |
| Table 5-6:  | GPI Out 1 Status .....                                     | 12 |
| Table 5-7:  | GPI Out 2 Status .....                                     | 12 |
| Table 5-8:  | GPI inputs in Auto Changeover mode.....                    | 12 |
| Table 5-9:  | DVB-ASI Exclusive Mode DIP Settings.....                   | 12 |
| Table 5-10: | DIP Setting for Input A Priority Mode.....                 | 12 |
| Table 5-11: | GPI inputs in Auto Changeover mode with GPI Override ..... | 13 |
| Table 5-12: | Manual Mode DIP Settings for Output 1.....                 | 14 |
| Table 5-13: | Manual Mode DIP Settings for Output 2.....                 | 14 |
| Table 7-1:  | <i>VistaLINK</i> ® Monitored Parameters .....              | 18 |
| Table 7-2:  | <i>VistaLINK</i> ® Controlled Parameters.....              | 18 |
| Table 7-3:  | <i>VistaLINK</i> ® Traps .....                             | 18 |

## REVISION HISTORY

| <u>REVISION</u> | <u>DESCRIPTION</u>  | <u>DATE</u> |
|-----------------|---|-------------|
| 0.1             | Preliminary Version   | Sept 03     |
| 1.0             | Updated section on ACO Extension mode   | Sept 03     |
| 1.1             | Added DVB-ASI Exclusive mode  | Oct 03      |
| 1.2             | Added VistaLINK <sup>®</sup> Support  | May 04      |
| 1.2.1           | Corrections made to Figure 6-1 and Section 6.2  | Jul 04      |
| 1.3             | Updated Table 5-1: Mode Selection DIP Settings<br>Added Section 5.3.2 Setting the Switching Priority Mode<br>Added Section 5.3.3 ACO1 Master Mode | Aug 04      |
| 1.4             | Added new ACO1 Master Mode with GPI Override (section 5.3.4)  | Feb 06      |
| 1.5             | Updated features and technical description  | Jan 07      |
| 1.6             | Updated available technical capabilities  | Jun 15      |

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof nor for the rights of third parties, which may be effected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance, either express or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.

*This page left intentionally blank*


## 1. OVERVIEW

The Evertz 500ACO2-HD/SD dual SDI Auto Changeover is designed to provide extension to the 5600ACO for HD or SD SDI, DVB-ASI, AES audio, bi-level/tri-level syncs and NTSC/PAL video. The unit can also be operated as a standalone changeover unit with two independent 2X1 banks. The 500ACO2-HD/SD uses latching relays to ensure maximum reliability and minimal disruption in the event of any failure.

The 500ACO2-HD/SD is housed in the 500FR **exponent** Frame that will hold up to 16 modules.

### Features:


- Auto detection of six signal types
- Five modes of operation (including VistaLINK<sup>®</sup>)
  - Auto changeover – two standalone auto-changeovers or two linked changeovers
  - Manual DIP Switch control – two independently controlled 2x1 switchers
  - GPI Control – two independently GPI controlled 2x1 switchers
  - ACO Extension – slave unit of the 5600ACO (require 5600ACO firmware version 1.2 or higher)
- Support for VistaLINK<sup>®</sup> monitoring and control
- Fully hot-swappable from front of frame with no BNC disconnect required
- Tally output on Frame Status bus upon loss of input signal for quality monitoring
- Ability to pass any 1Vp-p signal
- HD and SD will suffer slight loss in amplitude through relays (HD-15% loss, SD-5% loss)
- HD rise/fall times will be increased (HD rise/fall by 50%, SD by 15%)
- Signal is split from relays to detection logic (signals only validated in auto mode)
- Latching relays maintain the current path on loss of power



**Figure 1-1: 500ACO2-HD/SD Block Diagram**

## 2. INSTALLATION

The 500ACO2-HD/SD comes with a companion rear panel overlay that can be placed over the rear panel BNC connectors to identify their function. For information on inserting the module into the frame see section 3 of the 500FR manual.




**Figure 2-1: 500ACO2-HD/SD Rear Panel Overlay and Panel Adapter**

- IN A & Bs** Input BNC connector for HD & SD SDI, DVB-ASI, AES audio, and bi-level/tri-level sync signals.
- OUT 1 & 2** There are two latching relay outputs to pass either input A or B depending on user controls. **These outputs must be terminated with 75Ω.**
- GPI1 & 2** General purpose interface input connections
- GPO1 & 2** General purpose interface output connections

The K500AMDA-IO adapter has two 3 pin terminal blocks containing GPI and GPO connections. There are labels on the side of the terminal strips identifying the GPI1 and GPI2 inputs and GPO1 and GPO2 outputs. The GPI and GPO cables can be secured into the removable portion of the terminal strips using a small screwdriver. The removable part of the terminal strip is then inserted into the rear panel. Please refer to Figure 2-2 for additional information on installing the panel adapter.

## 2.1. INSTALLING THE GPIO PANEL ADAPTER

1. Using a Philips screwdriver, remove the M25x8mm screw at the bottom of the slot where you want to install the panel adapter.
2. Install the jack post that was supplied with the panel adapter. Tighten with pliers or a hex wrench.
3. Slide the BNC connectors of the panel adapter into the BNC connectors on the rear of the frame. The panel adapter should be pressed all the way in until it touches the jack post. Be sure to install the panel adapter with the rounded side facing upwards.
4. Reinstall the screw and tighten with a Philips screwdriver.




**Figure 2-2: K500AMDA-IO Rear Panel Adapter Installation**



**2.2. CONNECTING THE GENERAL PURPOSE INPUTS AND OUTPUTS**

The two, three pin terminal connector has two general purpose inputs and two general purpose outputs for control and status of the 500ACO2-HD/SD. The GPI wires can be secured into the removable portion of the terminal strips using a small screwdriver. The removable part of the terminal strip can then be inserted into the panel adapter.

The GPI inputs are considered high if they are left floating (not connected) or pulled up to +5 volts. The GPI inputs are considered low when the GPI input is pulled below 0.8 volts. The user can make the GPIs low simply by connecting the GPI input pins to ground using a button, switch, relay or an open collector transistor. Figure 2-3 shows the circuitry for each of the GPI input pins.




**Figure 2-3: GPI Circuitry**



**Maximum Voltage to GPI = 5V**  
**Maximum Resistance to GND to trigger GPI = 1K**  
**5V is the maximum voltage that should be applied to the GPI. A voltage higher than 5.9V will exceed the power dissipation of the 220Ω 0603 resistor.**

The GPO outputs are internally pulled up to 5 volts. Care must be taken to limit the load to 0.1W so there is no effect on the power supply of the module.

Figure 2-4 shows the circuitry for each of the GPO output pins.



**Figure 2-4: GPO Circuitry**

### 2.2.1. GPO Behaviour

**GPO1** = Low (GND) when ACO1 is on input A  
Hi-Z (open) when ACO1 is on input B

**GPO2** = Low (GND) when ACO2 is on input A  
Hi-X (open) when ACO2 is on input B

**GPO Maximum sink current** = 500mA

**GPO Maximum voltage** = 30V

The GPOs will always possess these behaviours in all modes expect for ACO Extension mode.



**When power is lost both GPOs will be open circuit.**

### 3. SPECIFICATIONS

#### 3.1. RELAY INPUTS

**Recognized Signal Types:** SMPTE 292M, SMPTE 259M A, B, C, D, DVB-ASI  
**Connectors:** 4 BNC per IEC 60169-8 Amendment 2  
**Maximum Cable Length:** 100m of Belden 1694A or equivalent cable combined input and output  
**Return Loss:** 10 dB up to 1.5 Gb/s  
**Maximum Signal Level:** 1Vp-p

#### 3.2. RELAY OUTPUTS

**Number of Outputs:** 2 passive relay outputs  
**Connectors:** BNC per IEC 60169-8 Amendment 2  
**Maximum Cable Length:** 100m of Belden 1694A or equivalent cable combined input and output  
**Return Loss:** 10 dB up to 1.5 Gb/s  
**DC Offset:** 0V  $\pm$ 0.5V

#### 3.3. GENERAL PURPOSE INPUTS AND OUTPUTS

**Type:**

**Inputs:** Opto-isolated input with internal pull-up to + 5volts.  
**Outputs:** Normally 10K internal pull-up to + 5volts. Ground to rear panel when relay is in active position.

**Connector:** Two 3 pin terminal blocks with one ground each.  
**Signal Level:** +5V nominal

#### 3.4. ELECTRICAL

**Voltage:** + 12VDC  
**Power:** 6 Watts  
**EMI/RFI:** Complies with FCC Part 15 Class A, EU EMC Directive

#### 3.5. PHYSICAL

**Number of slots:** 1

#### 3.6. SIGNAL PRESENT AND CHANGEOVER CONDITIONS

The input signals are considered present according to the following criteria:

**SDI:** Valid SD or HD carrier  
**DVB-ASI:** Valid SMPTE sync word  
**Sync:** H timing detect, NTSC and PAL/Tri-level (Sync pulse must be greater than 100mV)  
**AES:** Valid AES carrier

## 4. STATUS LEDS

The 500ACO2-HD/SD has 10 LED Status indicators on the front card edge to show operational status of the card at a glance. Figure 6-1 shows the location of the LEDs.

### 4.1. MODULE STATUS LEDS

Two large LEDs on the front of the board indicate the general health of the module

**LOCAL FAULT:** This Red LED indicates poor module health and will be ON if no valid input signals are detected or if a local input power fault exists (i.e.: a blown fuse). The LOCAL FAULT indication can also be reported to the frame through the FRAME STATUS jumper.

**MODULE OK:** This Green LED indicates good module health. It will be ON when at least one valid input signal is present, and board power is good.

### 4.2. SIGNAL PRESENT LEDS

There are four small green LEDs that indicate the presence of valid recognized input signal type.

### 4.3. INPUT SELECTED LEDS

There are four small green LEDs that indicate the current selected input for each 2X1 unit.

## 5. MODES OF OPERATION

The 500ACO2-HD/SD is equipped with a 4 position DIP Switch for selection of various modes of operations. Please refer to Table 5-1. Setting a DIP Switch UP (away from the circuit board) puts it in the Open position.

| #  | DIP Switch |       |       |       | Mode of Operation  | Description  |
|----|------------|-------|-------|-------|--|--|
|    | 1          | 2     | 3     | 4     |  |  |
| 1  | Close      | Close | Close | Close | VistaLINK® Remote Mode (Section 7)   | VistaLINK® remote control mode   |
| 2  | Close      | Close | Close | Open  | Auto Changeover (Section 5.3.3)<br>ACO1 Master Mode)   | Auto Changeover mode where ACO1 is the Master and ACO 2 follows ACO1. GPI reset to unlock after a switchover.  |
| 3  | Close      | Close | Open  | Close | Auto Changeover (Section 5.3.4)<br>ACO1 Master Mode with GPI Manual Override)                          | Auto-Changeover mode where ACO1 is the Master and ACO 2 follows ACO1. GPI can be used to override auto changeover and select an input for ACO1 (and ACO2). |
| 4  | Close      | Close | Open  | Open  | ACO Extension Mode (Section 5.1)   | Function as a slave unit of the 5600ACO  |
| 5  | Close      | Open  | Close | Close | Reserved   |  |
| 6  | Close      | Open  | Close | Open  | Reserved   |  |
| 7  | Close      | Open  | Open  | Close | Reserved   |  |
| 8  | Close      | Open  | Open  | Open  | GPI Control Mode (Section 5.2)   | GPI Control of two 2x1 switchers   |
| 9  | Open       | Close | Close | Close | Auto Changeover Mode (Section 5.3)<br>DVB-ASI Exclusive Mode Enabled<br>Input A Priority Mode Enabled  | Two standalone auto changeovers<br>Only DVB-ASI signals are considered valid<br>A Input has higher priority  |
| 10 | Open       | Close | Close | Open  | Auto Changeover Mode (Section 5.3)<br>DVB-ASI Exclusive Mode Disabled<br>Input A Priority Mode Enabled | Two standalone auto changeovers.<br>All supported signals are considered valid. An Input has higher priority.  |
| 11 | Open       | Close | Open  | Close | Auto Changeover Mode (Section 5.3)<br>DVB-ASI Exclusive Mode Enabled                                   | Two standalone auto changeovers.<br>Only DVB-ASI signals are considered valid.   |
| 12 | Open       | Close | Open  | Open  | Auto Changeover Mode (Section 5.3)<br>DVB-ASI Exclusive Mode Disabled                                  | Two standalone auto changeovers.<br>All supported signals are considered valid.  |
| 13 | Open       | Open  | Close | Close | Manual Control Mode (Section 5.4)  | DIP Switch control two 2X1 switchers.<br>Input 1 B is selected as output 1.<br>Input 2 B is selected as output 2.  |
| 14 | Open       | Open  | Close | Open  | Manual Control Mode (Section 5.4)  | DIP Switch control two 2X1 switchers.<br>Input 1 B is selected as output 1.<br>Input 2 A is selected as output 2.  |
| 15 | Open       | Open  | Open  | Close | Manual Control Mode (Section 5.4)  | DIP Switch control two 2X1 switchers<br>Input 1 A is selected as output 1<br>Input 2 B is selected as output 2   |
| 16 | Open       | Open  | Open  | Open  | Manual Control Mode (Section 5.4)  | DIP Switch control two 2X1 switchers.<br>Input 1 A is selected as output 1.<br>Input 2 A is selected as output 2.  |

**Table 5-1: Mode Selection DIP Settings**

### 5.1. ACO EXTENSION MODE

When the 500ACO2-HD/SD operates in ACO Extension mode it provides the capability to extend the changeover capabilities of the 5600ACO to switch HD or SD SDI, DVB-ASI, AES audio or additional analog video. The 5600ACO will act as the master and multiple 500ACO2-HD/SD can be used as slaved devices. In order to use the 500ACO2-HD/SD with the 5600ACO, the 5600ACO DIP Switch must be set to enable ACO Extension mode. The DIP Switch is located inside the 5600ACO, and is accessible by removing the top cover of the unit. To enable ACO extension mode set DIP Switch 1 to the ON (Closed) position. Multiple 500ACO2-HD/SD can be connected using the two available GPI outputs as shown in Figure 5-1.



**The Front Panel GPI operating mode of the 5600ACO will be disabled when it is operating in ACO Extension mode.**


When the 5600ACO is operating in ACO Extension mode, the 500ACO2-HD/SD modules will signal to the 5600ACO the status of all the inputs by means of the *GPO1* and *GPO2* outputs. The 5600ACO will decide if a changeover is necessary based on all the inputs on the 5600ACO, and its GPI inputs from all the 500ACO2-HD/SD connected on the wired OR bus. The 5600ACO provides control of the 500ACO2-HD/SD module's switches by means of its *ACO GPO1* output connected to the 500ACO2-HD/SD *GPI1*. Table 5-2 shows how the general purpose outputs are used to report status to the 5600ACO. The GPO status is an OR'ed condition from switch 1 and switch 2. The GPI2 is ignored.

| Input A | Input B | GPO1 | GPO2 |
|---------|---------|------|------|
| Present | Present | High | High |
| Missing | Present | Low  | High |
| Present | Missing | High | Low  |
| Missing | Missing | High | High |

**Table 5-2: GPO Operation in ACO Extension Mode**



**The 5600ACO firmware must be version 1.2 or higher to operate in this mode.**



**Figure 5-1: ACO Extension Mode Diagram**

**5.2. GPI CONTROL MODE**

In the GPI control mode, the output of each 2x1 can be independently selected using the two available GPI inputs, as described in Table 5-3 and Table 5-4. Please refer to section 2.2 for details on GPIO connections.

| Output 1 | GPI1 | GPO1 |
|----------|------|------|
| Input 1A | Low  | Low  |
| Input 1B | High | High |

**Table 5-3: GPI Control Mode for GPI in/out 1**

| Output 2 | GPI2 | GPO2 |
|----------|------|------|
| Input 2A | Low  | Low  |
| Input 2B | High | High |

**Table 5-4: GPI Control Mode for GPI in/out 2**

**5.3. AUTO CHANGEOVER MODE**

In Auto Changeover mode, input signals are validated. Upon loss of signal the auto changeover will switch to the backup signal on the corresponding input of each 2x1 independently. The behavior is summarized in Table 5-5. The GPI outputs are used for status reporting, and are described in Table 5-6 and Table 5-7. The output of both ACOs can be controlled with GPI inputs as described in Table 5-8

| Input A | Input B | Output         |
|---------|---------|----------------|
| Present | Present | Current output |
| Present | Absent  | A              |
| Absent  | Present | B              |
| Absent  | Absent  | Current output |

**Table 5-5: Auto changeover Behavior for each 2X1**

| Output 1          | GPO 1 |
|-------------------|-------|
| Input 1A selected | Low   |
| Input 1B selected | High  |

**Table 5-6: GPI Out 1 Status**

| Output 2          | GPO 2 |
|-------------------|-------|
| Input 2A selected | Low   |
| Input 2B selected | High  |

**Table 5-7: GPI Out 2 Status**

| GPI input 1 | GPI input 2 | Output of ACO1, and ACO2 |
|-------------|-------------|--------------------------|
| Low         | Low         | Current output           |
| Low         | High        | B                        |
| High        | Low         | A                        |
| High        | High        | Current output           |

**Table 5-8: GPI inputs in Auto Changeover mode**

### 5.3.1. DVB-ASI Exclusive Mode

While in Auto Changeover mode, activating the DVB-ASI Exclusive mode will force the 500ACO2-HD/SD to only validate DVB-ASI signals. All other input signals will be considered invalid.

| DIP Switch |       |   |       | Mode                        |
|------------|-------|---|-------|-----------------------------|
| 1          | 2     | 3 | 4     |                             |
| Open       | Close | X | Open  | Normal auto changeover mode |
| Open       | Close | X | Close | DVB-ASI Exclusive Mode      |

**Table 5-9: DVB-ASI Exclusive Mode DIP Settings**

### 5.3.2. Setting the Switching Priority Mode

With firmware version 1.5 and later, the DIP Switch 4 controls whether the 500ACO2 operates with input A at a higher priority or equal priority as input B. When input A has higher priority, the 500ACO2 will switch back to input A if the input signal becomes valid again.

| DIP 4 | Input A Priority Mode             |
|-------|-----------------------------------|
| Off   | Input A and B have equal priority |
| On    | Input A has higher priority       |

**Table 5-10: DIP Setting for Input A Priority Mode**



### 5.3.3. ACO1 Master Mode

*Available with firmware version 1.6 and later.*

In this mode, the 500ACO2 will monitor signal validity of ACO1's A input. On failure, both ACO1, and ACO2 will switch to B input regardless of signal validity. Both ACOs will now be locked in this state, until GPI inputs are set as described in Table 5-8.

### 5.3.4. ACO1 Master Mode with GPI Override

*Available with firmware version 1.7 and later.*

In this mode, the 500ACO2 will monitor signal validity of ACO1's A input. On failure, both ACO1 and ACO2 will switch to B input regardless of signal validity. Both ACOs will now be locked in this state, unless GPI inputs are set as described in Table 5-11.

| GPI input 1 | GPI input 2 | Output of ACO1, and ACO2                  |
|-------------|-------------|---|
| Low         | Low         | Current output, re-enable auto changeover |
| Low         | High        | B, disable auto changeover                |
| High        | Low         | A, disable auto changeover                |
| High        | High        | Current output, re-enable auto changeover |

**Table 5-11: GPI inputs in Auto Changeover mode with GPI Override**

#### 5.4. MANUAL DIP SWITCH CONTROL MODE

In manual control mode, the DIP Switch selection will override all other controls. The selection is described in Table 5-12 and Table 5-13.

| DIP Switch |      |       |   | Output 1 Selection |
|------------|------|-------|---|--------------------|
| 1          | 2    | 3     | 4 |                    |
| Open       | Open | Open  | X | Input 1 A          |
| Open       | Open | Close | X | Input 1 B          |

**Table 5-12: Manual Mode DIP Settings for Output 1**

| DIP Switch |      |   |       | Output 2 Selection |
|------------|------|---|-------|--------------------|
| 1          | 2    | 3 | 4     |                    |
| Open       | Open | X | Open  | Input 2 A          |
| Open       | Open | X | Close | Input 2 B          |

**Table 5-13: Manual Mode DIP Settings for Output 2**

## 6. JUMPERS AND USER ADJUSTMENTS



Figure 6-1: LED and Jumper Locations

## 6.1. SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED BY THE GLOBAL FRAME STATUS

The FRAME STATUS jumper J2, located at the front of the module, determines whether local faults (as shown by the Local Fault indicator) will be connected to the 500FR frame's global status bus.

**FRAME STATUS:** To monitor faults on this module with the frame status indicators (on the power supply's FRAME STATUS LED's and on the Frame's Fault Tally output), install this jumper in the ON position.

When this jumper is installed in the OFF position local faults on this module will not be monitored.

## 6.2. CONFIGURING THE MODULE FOR FIRMWARE UPGRADES

### UPGRADE

The UPGRADE jumper J3 is located at the front of the module and is used when firmware upgrades are being performed on the module. For normal operation it should be installed in the *RUN* position. See the *Upgrading Firmware* section in the front of the binder for more information.

To upgrade the firmware in the module unit pull it out of the frame. Move Jumper J3 into the *UPGRADE* position. Install the Upgrade cable provided (located in the vinyl pouch in the front of this manual) onto header J1. Re-install the module into the frame. Perform the upgrade as described in the *Upgrading Firmware* section in the front of the binder. Once the upgrade is complete, remove the module from the frame. Move J3 into the *RUN* position, remove the upgrade cable and re-install the module. The module is now ready for normal operation.

## 7. VistaLINK<sup>®</sup> REMOTE MONITORING/CONTROL

### 7.1. WHAT IS VistaLINK<sup>®</sup>?

VistaLINK<sup>®</sup> is Evertz's remote monitoring and configuration platform which operates over an Ethernet network using Simple Network Management Protocol (SNMP). SNMP is a standard computer network protocol that enables different devices sharing the same network to communicate with each other. VistaLINK<sup>®</sup> provides centralized alarm management, which monitors, reports, and logs all incoming alarm events and dispatches alerts to all the VLPro Clients connected to the server. Card configuration through VistaLINK<sup>®</sup> PRO can be performed on an individual or multi-card basis using simple copy and paste routines, which reduces the time to configure each module separately. Finally, VistaLINK<sup>®</sup> enables the user to configure devices in the network from a central station and receive feedback that the configuration has been carried out.

There are 3 components of SNMP:

1. A SNMP manager, also known as a Network Management System (NMS), is a computer running special software that communicates with the devices in the network. Evertz VistaLINK<sup>®</sup> Pro Manager graphical user interface (GUI), third party or custom manager software may be used to monitor and control Evertz VistaLINK<sup>®</sup> enabled products.
2. Managed devices (such as 500ACO2-HD/SD), each with a unique address (OID), communicate with the NMS through an SNMP Agent. Evertz VistaLINK<sup>®</sup> enabled 500 series modules reside in the 3RU 500FR MultiFrame and communicate with the manager via the 500FC VistaLINK<sup>®</sup> frame controller module, which serves as the Agent.
3. A virtual database, known as the Management Information Base (MIB), lists all the variables being monitored, which both the Manager and Agent understand. Please contact Evertz for further information about obtaining a copy of the MIB for interfacing to a third party Manager/NMS.

For more information on connecting and configuring the VistaLINK<sup>®</sup> network, see the 500FC Frame Controller chapter.

## 7.2. VistaLINK® MONITORED PARAMETERS

The following parameters can be remotely monitored through the VistaLINK® interface.

| Parameter              | Description  |
|------------------------|--|
| Module Status          | Indicates the health of the card                     |
| Master jumper          | Indicates remote or local control of the card        |
| Operating Mode         | Indicates the selected operating mode                |
| DVB-ASI Exclusive Mode | Indicates the selection for DVB-ASI exclusive mode   |
| Signal Presence 2B     | Indicates the presence of a valid signal on input 2B |
| Signal Presence 2A     | Indicates the presence of a valid signal on input 2A |
| Signal Presence 1B     | Indicates the presence of a valid signal on input 1B |
| Signal Presence 1A     | Indicates the presence of a valid signal on input 1A |
| Signal Standard 2B     | Indicates the signal standard on input 2B            |
| Signal Standard 2A     | Indicates the signal standard on input 2A            |
| Signal Standard 1B     | Indicates the signal standard on input 1B            |
| Signal Standard 1A     | Indicates the signal standard on input 1A            |
| ACO 2 Output           | Indicates the currently selected output ACO unit 2   |
| ACO 1 Output           | Indicates the currently selected output ACO unit 1   |

**Table 7-1: VistaLINK® Monitored Parameters**

## 7.3. VistaLINK® CONTROLLED PARAMETERS

| Parameter              | Description  |
|------------------------|--|
| Operating Mode         | Indicates the selected operating mode              |
| DVB-ASI Exclusive Mode | Indicates the selection for DVB-ASI exclusive mode |
| ACO 2 Output           | Indicates the currently selected output ACO unit 2 |
| ACO 1 Output           | Indicates the currently selected output ACO unit 1 |

**Table 7-2: VistaLINK® Controlled Parameters**

## 7.4. VistaLINK® TRAPS

| Parameter          | Description  |
|--------------------|--|
| Module Status      | Indicates the health of the card                     |
| Signal Presence 2B | Indicates the presence of a valid signal on input 2B |
| Signal Presence 2A | Indicates the presence of a valid signal on input 2A |
| Signal Presence 1B | Indicates the presence of a valid signal on input 1B |
| Signal Presence 1A | Indicates the presence of a valid signal on input 1A |

**Table 7-3: VistaLINK® Traps**